



## Instructions for the firmware update Metz mecablitz with USB-Port:

### 1. System requirements:

- Mac with OSX 10.6 - 10.12 operating system.
- Permission (administrator rights) to install a USB driver and a free USB port.

### 2. Procedure:

- 2.1 Use a standard USB cable to connect the flash unit to the computer and let the flash unit connected.
- 2.2 Download of the software from [www.metz-mecatech.de](http://www.metz-mecatech.de).
- 2.3 Copy the self-extracting file, e.g. "MB\_52\_AF\_1\_Nikon\_V2.3\_GB\_Mac.zip", into a file of your home directory (e.g. mac\_user\ ) and execute it.  
**Attention:** Please doesn't use file names with blanks! This may result in errors. Instead of blanks use underlined.
- 2.4 The zip file is extracted and a file with the same name will occur. This file includes 2 subfolders.
- 2.5 The subfolder "Driver" includes the driver software). The driver software will be installed by double-click. After that you only have to confirm to which hard disk the driver should be installed.  
Attention: the driver installation isn't necessary onwards OSX 10.8.

### 3. Start of the update:

- 3.1 The software "FirmwareUpdater\_...." (workable file in the extracted directory "FirmwareUpdater\_Mac") can be started by double-click. Accept the Terms of Use by clicking "Yes".
- 3.2 Start the firmware update by clicking "Start".
- 3.3 After the update procedure, you have to wait for the data to be checked.
- 3.4 After the data check, the window "Update successful finished!" appears. Finish the update procedure by clicking "OK". After that the flash unit can be unplugged.



If you want to re-program other flash units of the same type, you can leave the "Firmware Update" open. In this case, remove the first flash unit from the USB cable and connect another one. After waiting for approximately 5 seconds, you can start the update procedure by clicking "Start".

### **Metz mecatech GmbH**

Ohmstrasse 55

90523 Zirndorf

Germany

Phone: +49 911 9706172

Fax: +49 911 9706359

E-Mail: [support-mb@metz-mecatech.de](mailto:support-mb@metz-mecatech.de)